

REFLECTING COLT TRADITION OF FINE CRAFTSMANSHIP SINCE 1836

COLTEER .22 AUTOLOADER

From its true Western stock with classic straight lines, to its hooded Gold Bead front sight, this carbine combines old and new into a truly fine firearm, deserving of the famous Colt trademark. Its modern, autoloading action gives you the ultimate in a lightweight, easy-handlin' automatic for small game, varmints or just plain plinking. Has American walnut stock and fore-end. Barrel band on fore-end adds to its sporty look. Western style open rear sight adjustable for elevation and windage. Positive crossbolt safety. Weighs just 4½ pounds. Over-all length is 37°. Receiver is grooved for "lipoff" scope mounting. Tubular magazine holds 15.22 Long Rifles, Regular or High Speed. Here's a rille you'll be proud to own. Made in Hartford, Conn. by Colt craftsmen.



GENERAL OPERATING INSTRUCTIONS

Ammunition—Shoots all .22 long rille ammunition, regular or hi-speed.

Safety—The Safety button (40) is located at the rear of the trigger guard (60). Slide Safety button from left to right to lock in "safe" position. Slide Safety button from right to left for "fire" position. When Safety button is in "fire" position, a band of red appears on the button, indicating the rifle is ready to fire.

OPERATION

To Load—Grasp magazine cap (30) and turn counterclockwise to release. Withdraw inner magazine tube from outer magazine tube until the loading port in outer magazine tube is open. Load from one to 15 cartridges in loading port, then push inner magazine tube back into position and lock.

Chamber may now be loaded by pulling cocking handle (39) to its extreme rear position and allowing it to go forward to closed position. After loading chamber, one more cartridge may be fed into the magazine for full fire load of 16 shots.

The gun may now be fired by pulling the trigger. Only one shot will fire with each pull of the trigger. Trigger must be released and pulled again for each additional shot.

ALWAYS keep Rifle on Safe until you are ready to fire it.

To Unload—Put Rifle on "Safe". Remove inner magazine tube and point muzzle down so that cartridges will slide out of magazine tube. Retract bolt to extract round in chamber. Check magazine throat before closing bolt to make sure there is not an additional cartridge in position to feed into chamber.

Replace inner magazine tube, then open and close the bolt several times while looking in the ejection port to make sure there are no cartridges in the magazine, and that the chamber is empty.

Always treat the rifle as if it were loaded, even when you are sure it is empty.

To Disassemble—Check rifle to make sure it is not loaded. Remove inner magazine tube (32). Remove forearm screw (16) and barrel band screw (35). Slide barrel band off forearm (15). Remove forearm. Drive out pin (61). Pull back cocking handle to extreme rear. With bolt in this position, trigger guard assembly can be removed by pulling out just forward of the trigger guard. Bolt can then be removed by pulling back slightly on the cocking handle and pulling bolt out thru bottom of receiver. Bolt spring assembly (39) may now be removed easily. To function properly, moving parts should be kept clean and free of powder residue and oiled very lightly.

We do not recommend disassembly beyond this point, except by qualified persons or gunsmiths.

Do not pull trigger while trigger guard is removed from nile as this puts undue strain on hammer and hammer stop pin. Reassemble rille by reversing the above procedure.

Sighting—Your rifle has been sighted at the factory to hit point of aim at 50 yards. We recommend that you sight-in your rifle personally to compensate for a possible difference in sighting vision. The rear sight is adjustable for both windage and elevation.

COMPAR SALVINO ROLLINGS

WESTERN STYLE STOCK - stock and fore-end made of solid American walnut.

REPEATING MECHANISM - a highly reliable semiautomatic repeating mechanism. The ultimate rifle, ideal for small game, varmints or just plain plinking.


CROSS BOLT SAFETY - a positive safety lock, shows

red when safety is OFF and rifle is ready to fire.


SIGHTS - Western style open rear sight adjustable for elevation and windage, hooded gold bead front sight. Receiver grooved for "tip-off" scope mounting.



BARREL BAND - on fore-end adds to rifle's sporty look.




Hooded Gold Bead Sight. Tubular Magazine holds 15 rounds.



View of automatic repeating mechanism, open rear sight and safety.

To disassemble the Colteer .22 beyond the point described under "General Operating Instructions," the rifle should be brought to a qualified gunsmith, as would be done with any fine firearm.

Under terms of Warranty, Colt responsibility to the owner is limited to the extent that such disassembly be performed only by Colt Custom Repair Department.



Reference numbers are for illustration purposes only.
Use part numbers when ordering parts.

NO.	NAME OF PART	PART NO.
ī	Barrel Assembly	80397
Ž	Barrel Relaining Pin	P6123
3	Boll	60124
4 5	Bull Pizie Butl Piate Screw (2 uzed)	80081 93501
	Slock	E0914
6 7 8	Cleater Assembly	80222
	Edractor	80863
9	Latractor Spring	80188
10	Extractor Spring Plunger	60168
ii.	Fixing Pin.	80128
12 13	Firing Pin Retaining Pin	95008 80128
14	Follower Spring	80130
15	Foreirm	80347
16	Forearm Screw	80132
17	Front Band LH	70115
17	Front Band R.H.	70118
18	Front Band Screw	80325
19	Front Sight Bead	80361
20 21	Frant Sight Hood Frant Sight	80351 80350
22	Front Sight Screw	80340
23	Harmer	80133
24	Hammer Spring	80134
25	Hammer Spring Pin	80306
76	Lifter	80135
27	Liller Cam Pin.	85143
72	Uller Pin.	95008
29 30	Lifter Spring. Magazine Tube Cap	60138 80139
ກັ	Magazina Tube Cap Pm	95007
32	Marazine Tube, Inner	80137
ij	Magazine Tube, Inner, Magazine Tube, Outer	60323
34	Rear Band	70102
35	Rear Band Scrow	70090
36	Reur Sight Leaf	84119
37 38	Rear Sight Livrator	84952
39	Record Spring Assembly.	60743
40	Salety	80143
41	Salety Detent Spring. Spring Detent (2 used) (Sear & Salety)	80317
42	Spring Detent (7 used) (Sear & Salety)	80144
0	Sear	60857
45	Seaf Bar	80148
45	Sear Bar Pin Sear Bar Spring L.H.	80306
17	Sear Bar Spring R.H.	80147
ii.	Sear Bar Spring Pin	80318
49	Case & Case Day Politicing Con	80305
50	Sear Owtern Spring Spring Delent (2 used) (Sear & Safety)	80146
51	Spring Defect (2 used) (Sear & Safety)	80144
23 23	Stock Bolt Stock Bolt Lock Washer	B3601
27	Stock Bolt Wesher	80002
54 55 56 57	Throat Lit.	90Z0Z
56	Throat R.H.	80161
57	Throat Pur (Z esed)	80150 80901
55	Trigger Assembly	80389
59	Trigger Bushing (Z used)	80165
60	Trigger Guard	60163
61 82	Trigger Gaard Pin Trigger Pin	60307
D D	Torrer Spone	8500B
ŭ	Tripper Slap Pin	80903
65	Trigger Stop Pin. Magazina Tuba Retaining Pin.	95008
66	Barrel Band Pts.	95704 95114

FOR THE FINEST IN SHOOTING EQUIPMENT — OLT since 1836

This rifle is styled after the heavier caliber carbines of the old west. Behind this picturesque styling is the newest semi-automatic repeating mechanism modern technology has produced. Other features include western style open rear sight, black walnut stock and fore end, saddle ring and rolf engraved frame. A fast rugged, accurate .22, every inch the outdoorsman's rifle.

COURIER AUTOLOADING RIFLE

22 Long Rifle, Regular or High Speed. The shooting comfort of a pistol grip type stock and streamlined appearance of a tapered, hand-filling fore-end . . . both of solid walnut, combine to deliver a thoroughly modern .22 autoloader of exceptional reliability. Lightweight . . . 444 pounds. Receiver dovelail grooved for tip-off scope mount. Shoots .22 long rifle, standard or high velocity ammo.

